

INSTALLATION INSTRUCTIONS

REGUPOL EQUILINE IMPACT



For bonding onto stable and box walls
REGUPOL equiline impact

1. General information

The installation instructions below assume the necessary technical and craftsmanship standards for this work. The installation instructions are based on **REGUPOL's** current knowledge and will be modified as necessary. Neither the manufacturers nor dealers or distributors of **REGUPOL equiline impact** flooring have any direct influence on the correct installation and processing of the materials used. For these reasons, these installation instructions can only be regarded as non-binding and **REGUPOL** can accept no liability for the result of the work.

Responsibility for the correct condition of the supplied **REGUPOL equiline impact** sheets and panels lies of course with **REGUPOL**, provided that no alterations or damage by third parties have taken place from the time of shipment onwards. In this regard, please refer to our general terms and conditions of sales and delivery

REGUPOL equiline impact is resistant to liquids and sunlight, but should, however, be stored in an environment that protects it from moisture and UV rays before installation. The flooring should also be protected from chemicals, oils, grease, etc. In addition to these installation instructions, the processing instructions and, if applicable, the safety data sheets of the adhesive manufacturers and the manufacturers of other auxiliary materials and accessories must be observed

2. Wall surface

REGUPOL equiline impact can be bonded to most sound substrates. The wall surface to be covered must have the strength and durability required to withstand the permanent installation of the **REGUPOL equiline impact** sheeting.

The wall surface must be flat and even with a maximum permissible deviation of less than 5 mm over 3 m in any direction (measured with a 3 m straight edge). Depending on the condition of the surface, a suitable adhesion primer should also be used.

3. Material inspection

REGUPOL equiline impact wall covering is delivered packed in foil and labelled appropriately. An inspection of the individual rolls must be carried out before installation begins to make sure they are complete and free from any defects.

In general, any claims for compensation are only possible for goods which have not been installed or cut.

Slight deviations in colour and decor in **REGUPOL equiline impact** sheeting from different production batches cannot be ruled out completely. Any defects must be reported to the manufacturer immediately, stating the order and batch number as well as a description of the defect before installation begins.

4. Recommended installation

Once the sub-base has been properly prepared, all rolls supplied for the intended installation area must be laid out unprocessed and free of tension (roll out the rolls completely without cutting to size). The floor covering can now acclimatise for a period of approx. 8 hours at a constant room temperature of between approx. 18 °C to approx. 25 °C.

The rolls must be laid when dry. Any moisture or dampness caused by light rain during the installation process can cause serious problems and must be prevented.

The dimensional tolerances due to production and material factors are ± 0.8 mm for thickness.

Prior to bonding, the sheets must be cut to size with a cutter knife. Then a suitable contact adhesive must first be stirred up thoroughly before it is used for the installation of **REGUPOL equiline impact** sheeting. All sheets must be acclimatised, relaxed and laid flat and level.

INSTALLATION INSTRUCTIONS

REGUPOL EQUILINE IMPACT



The adhesive is then applied evenly to the surface of the sheeting and the wall.

This can be done with a brush, a roller or a smooth or fine-toothed spatula. Always take care to avoid of blobs and bubbles. The correct amount of adhesive depends on what kind of surface the sheeting is being applied to. Be sure to achieve sufficient surface wetting. And always follow the instructions of the adhesive manufacturer. After the flash-off time has elapsed, press the dry adhesive surfaces together and rub or roll them thoroughly.

The strength of the adhesive depends on the level of contact pressure applied.

The sheets can be installed edge to edge or with a 5 mm wide joint, which can then be sealed with a one-component PUR adhesive sealant (such as **REGUPOL adhesive 40-201**).

Joint sealing should be carried out after 24 hours at the earliest.

5. After installation

After installation, the wall covering should be left to rest for at least 24 hours.

6. Application advice

If you have any questions about the installation and maintenance of **REGUPOL equiline** products, feel free to contact your **REGUPOL** customer service advisor:

Tel.: +49 2751 803 141 | equestrian@regupol.eu